Instruction Sheet

Kit Number: 79107000

LIGHTWEIGHT-OPERATOR SEAT-SPRING KIT



WARNING: FAILURE TO FOLLOW

INSTRUCTIONS could result in personal injury and/or damage to unit.

Read, understand, and follow all safety practices in Operator's Manual before beginning.

Package Contents

Check the contents of your kit for the parts listed below. Also see Figure 1.

lte	m Description	Qty	Ariens P/N
1	Compression Seat Spring	2	08300703



REMOVAL

- 1. Stop engine, remove key and engage parking brake. Wait for moving parts to stop and for hot parts to cool.
- 2. Disconnect spark plug wires.
- 3. Rotate steering levers out and rotate seat forward into service position. See Figure 2.



4. Support the round-head square neck bolt from under the frame and remove and retain two 5/16" x 3 3/4" coupling nuts and two flat steel washers retaining seat springs. Remove and retain springs for operation with heavier-weight operators. See Figure 3.



INSTALLATION

 From below, support round head square neck bolts and install two compression seat springs (item 1) onto frame crossmember using two flat steel washers and two coupling nuts just removed. See Figure 4.



- 2. Reconnect spark plug wires.
- 3. Return seat and steering levers to operating position.